## **ACN BROADBAND TECHNICAL FAQ**

A. How to change your Wi-Fi password / Wi-Fi Username?






- 1. Connect to the Wi-Fi / LAN Cable,
- 2. Open the web browser (Google chrome / Firefox). Type in the address bar "10.0.0.10".
- 3. BDCOM Router will open.

I	10.0.0.10/admin/login.asp

UserLogin		
Password:	user  Login Reset	
Language	Select: English V	


- 4. The default Username of the device will be "user".
- 5. The default Password of the device will be "123456"
- 6. Then enter Login.



- 7. Click on "WLAN".
- 8. Click on Basic Settings.



- 9. To set your Wi-Fi Name click on **SSID** (Service Set Identifier) box.
- 10. Type your desired Wi-Fi name in the option provided as "SSID".
- 11. Select channel Width as 40Mhz
- 12. After giving your Wi-Fi name, click on "**Apply Change**", Then Click **Ok**, to save your settings. Please Confirm that the "Disable WLAN Interface / Hide SSID" option is not checked. This will hide your Wi-Fi from all connected devices.
- 13. To set your Wi-Fi Password, Click on "Security"



- 14. Set your Encryption as "WPA2 Mixed". Pre-shared Key Format as "passphrase".
- 15. Enter your desired password. In "**Pre-shared Key**" box, your password length has to be between 8 to 64 characters with at-least 1 Uppercase and 1 Special Character.
- 16. Then Click on "Apply Change" to save your settings.
- 17. Then Logout Successfully.

